


www.skyfactory.com • toll free 1.866.759.3228

Aperture w/ EcoPlus Installation Instructions



Installation Packet Includes:

Aperture w/ EcoPlus Installation Instructions Drop Ceiling and Hard Ceiling Cross-Sections included One of three Custom EcoPlus Electrical Packets Custom EcoPlus Electrical Packet (24PS HLG) Custom EcoPlus Electrical Packet (HLG) Custom EcoPlus Electrical Packet (Fixture Only) Luminous SkyTile Installation SkyTile Layout Grid Plan GR1 Suspension Layout SP1 Electrical Layout EL1 Electrical Layout EL2 Grid Detail DE2-4

If any of these documents are missing, please contact the Sky Factory for replacements before beginning installation.

<u>Important</u>: All subcontractors involved must have a copy of these specifications. All specifications must be followed in all stages of on-site manufacture or installation or warranty may be voided. Any deviation in the installation specifications may alter the final product and could result in a major increase in cost. Please review all documents enclosed before installation.

For technical support at any time during the installation, please call us **toll free at 866-759-3228.** We want your installation to go as smoothly as possible. Thank you for choosing Sky Factory.

Table of Contents

Installation Requirements

	Tools and Parts	2-4
	Location Requirements	5
	Suspension Requirements	6
	Electrical Requirements	7
	Fixture and SkyTile Orientation	7
lr	nstallation Instructions	
	Step 1: Create ceiling opening	8
	Step 2: Plan for electrical	8
	Step 3: Determine SkyTile orientation	9
	Step 4: Attach suspension cables to building structure	9
	Step 5: Lift fixture into position	9
	Step 6: Secure fixture to suspension system	10

Step 7: Connect power	10
Step 8: Draw fixture up against grid or finished ceiling	11
Step 9: Center fixture in opening	12
Step 10: Align trim and attach safety cables	12
Step 11: Engage trim clips	13
Step 12: To disengage trim clips (where required)	13
Step 13: Trim joint alignment (5x8 only)	14
Final Inspection List	15
Care and Maintenance	15
Gripple Butterfly Trapeze Installation Guide	16
Appendix A: How to free stuck Gripple cables	17
Grid Ceiling Cross Section	18
Hard Ceiling Cross Section	19


Installation Requirements

Tools and Parts

Tools Needed:

Tools to attach suspension system to building structure Needlenose pliers, measuring tape, level and other hand tools Tools for installing electrical and running conduit (where required)


Parts Provided:




Sky Factory

Parts Needed:


for AC Source power



for DC power



Suspension




Location Requirements

Aperture SkyCeilings require selecting a location for the following components:

SkyCeiling
 Dimmer or in-line power switch
 AC to DC power supply

SkyCeiling

- suspension anchor points must meet local and national codes
- must be dry and accessible for periodic cleaning
- can be installed in ceiling grid or imbedded in finished ceiling
- minimum space required above finished ceiling or grid: 6 7/8" (17.5cm) not including means to connect suspension to building structure



• SkyFactory 24PS HLG shown

Suspension Requirements

Fixture Suspension

Gripple Butterfly Trapeze suspension system (provided)

- 5' (152cm) stainless steel cable with loop end anchored to building structure
- Suspension anchor points not provided and must meet local and national codes
- See drawing SP1 for suspension locations

Trim Suspension

Sugatsune suspension system (provided)

Panel clips secure trim to fixture

Safety cables with 5" reach help secure trim during installation and provide backup once trim is fully secured

SkyCeiling Dimensions and Weights

AP-CIR-3

7 3/8" high
32 1/2" EcoPlus light box outside dia.
36" trim outside dia.
23 lbs ; 5.8 lbs per suspension point

AP-CIR-4

7 3/8" high44 1/2" EcoPlus light box outside dia.48" trim outside dia.40 lbs; 10 lbs per suspension point

AP-CIR-5

7 3/8" high
56 1/2" EcoPlus light box outside dia.
60" trim outside dia.
63 lbs; 15.8 lbs per suspension point

AP-ELP-4X6

7 3/8" high
44 1/2" x 68 1/2" EcoPlus light box outside dim.
48" x 72" trim outside dim.
61 lbs; 15.3 lbs per suspension point

AP-ELP-5X8

7 3/8" high
56 1/2" x 80 1/2" EcoPlus light box outside dim.
60" x 84" trim outside dim.
101 lbs; 16.9 lbs per suspension point

AP-CIR-3-M 18.8cm high 81cm EcoPlus light box outside dia. 90cm trim outside dia. 10.5kg; 2.7kg per suspension point AP-CIR-4-M 18.8cm high 111cm EcoPlus light box outside dia. 120cm trim outside dia. 18.2kg; 4.6kg per suspension point AP-CIR-5-M 18.8cm high 141cm EcoPlus light box outside dia. 150cm trim outside dia. 28.6kg; 7.2kg per suspension point AP-ELP-4X6-M 18.8cm high 111cm x 171cm EcoPlus light box outside dim. 120cm x 180cm trim outside dim. 27.7kg; 7.0kg per suspension point AP-ELP-5X8-M 18.8cm high 141cm x 231cm EcoPlus light box outside dim. 150cm x 240cm trim outside dim. 45.9kg; 7.7kg per suspension point

Electrical Requirements

At 24V DC:

 AP-CIR-3 Series
 @ 01.6A, 38.4W
 AP-ELP-4X6 Series
 @ 4.8A, 115.2W

 AP-CIR-4 Series
 @ 2.9A, 69.6W
 AP-ELP-5X8 Series
 @ 8.2A, 196.8W

 AP-CIR-5 Series
 @ 4.7A, 112.8W
 AP-ELP-5X8 Series
 @ 8.2A, 196.8W

See one of three electrical packets:

Custom EcoPlus Electrical Packet (24PS HLG),


Custom EcoPlus Electrical Instructions (HLG), or


Custom EcoPlus Electrical Instructions (Fixture Only)

Electrical work must be performed by a qualified electrician who is familiar with DC lighting systems and must conform to all local and national codes.

Fixture and SkyTile Orientation

Fixtures MUST be installed so the SkyTile fits the SkyTile Layout. SkyCeiling images are composed with a head/foot orientation. See **SkyTile Layout** included.





Step 2: Plan for electrical

See:

- Location Requirements on page 5
- Step 7: Connect Power
- Custom EcoPluS Electrical Packet provided

Step 3: Determine SkyTile orientation

- See page 7
- IMPORTANT: Be sure to orient the fixture following the **SkyTile Layout** sheet. If the SkyTile is improperly oriented, the fixture will have to be removed from the SkyCeiling and re-installed in the proper orientation.

cable provided

has loop type end

Step 4: Attach suspension cables to building structure

See:


- SP1 for SkyCeiling suspension points
- "Suspension Requirements" on page 6 for SkyCeiling weights


Attach cables to building structure following all local and national codes


Ensure cables extend at least 3" (8cm) below Gripple when fully installed.


Step 5: Lift fixture into position


IMPORTANT: Lift fixture by sidewall or ceiling stops. DO NOT LIFT AGAINST SKYTILE. <u>Do not overflex fixture when positioning</u>. Too much flexion could crack SkyTile.














Final Inspection List

Is the trim seated up against the grid flange or finished ceiling?

- If not, make sure all panel clips are engaged.
- Height of fixture in relation to finished ceiling or grid may need to be adjusted.

If Ap-Elp-5x8, have trim joint alignment clips been adjusted?

• If not, make sure all alignment clips are engaged and trim lines up at joints.

In grid ceiling applications, does the fixture sit evenly in the grid?

- If not, fixture alignment may need adjusting.
- If grid is not installed square, fixture may sit unevenly in the opening. If so, adjust grid so it is square.

Is the image evenly lit?

• If not, contact Sky Factory.

Does the SkyCeiling image match the SkyTile Layout image?

• If the SkyTile Layout has a head location, make sure the SkyCeiling is properly oriented in the room. If not, it should be reinstalled.

Has the arrow-label been removed once the image has been verified? If not, remove it now.

• Quick release label MUST be removed once the SkyTile is fully installed and checked for proper orientation.

Care and Maintenance

- Avoid scratching SkyTile and Trim when cleaning.
- Once installed, SkyTile and Trim can be cleaned in place.
- Use a mild soap and water solution, and a soft, damp-only, non-abrasive cloth.
- DO NOT wet edges of SkyTile. Water may cause image film to de-laminate.

Butterfly Trapeze Hanger

Cable hanger with one-way fastener or the fast suspension of rectangular duct and similiar equipment in an indoor stationary setting. NOT suitable for use in chlorinated / swimming pool environments.

FEATURES / BENEFITS

- Attaches to side of duct with self-drilling screws (not provided) •
- Rubber pad prevents air leakage and dampens vibration
- Simple height adjustment using the built-in release pin prior to applying load •
- Conforms to DW144 Class D

INSTALLATION & ADJUSTMENT

. Ideal for rectangular duct suspended close to the ceiling; can also be used for multi-tiered installations

b

Dimension

D

Е

Safe Working Load:

No.2 - up to 100 lbs@5:1 safety factor

(inches)

0.35

2.00

Supplied as a ready-to-use kit comprising a length of cable with pre-. attached end fixing

2. З. Adjust. 1. 1. Remove load

Ensure a minimum 3 inches of tail cable exit the hanger.

С 5:1)

副

(inches)

1.54

1.50

0.71

Dimension А

В

SIZE SPECS

FASTENER SPECS	

Housing - Type ZA2 Zinc Wedge - Sintered steel hardened to min. 56 Rockwell C Spring - Stainless Steel (Type 302) End Cap - UV stabilized homopolymer propylene Rubber Pad - EPDM 40±5 SHORE A Pin - A2 Stainless Steel

PI-BTRAPEZE-US

www.gripple.com

Gripple's policy is one of continuous development and innovation We therefore reserve the right to alter specifications, etc. without notice.

Tel +1 866 474 7753 Fax +1 800 654 0689 Email grippleinc@gripple.com




CABLE SPECS

Galvanized high tensile steel cable to EN12385. Standard lengths from 5ft-30ft, other lengths can be made to order.


	No.2
Cable Diameter	5/64"
Strand Configuration	7x7
Min. Breaking Load	500 lbs
Max. Safe Working Load	100 lbs
Tensile Strength (lbs/sq.in.)	256,700






Appendix A: How to Free Stuck Gripple Cables


If cable is wedged too tightly and won't release::




Step 1: Support fixture so cable is not carrying load



Step 2: Grip cable with pliers against bottom of Gripple



Step 3: Gently roll cable sideways while wedging pliers against Gripple



Step 4: When cable is loosened pull down on pin

NOTE: If a Gripple is damaged beyond repair, an extra Gripple with stand-offs and machine screws is included

